





RAILFX OASIS™ SECONDARY HANDRAIL INSTALLATION INSTRUCTIONS

Note: Read through all instructions before installation.
For ADA compliance, reference the RailFX Oasis™ ADA installation instructions.
Prior to installation, check with officials for local code requirements.


**IMPORTANT: HANDRAIL NOT COMPATIBLE WITH ADA COMPLIANT
RAILING SYSTEMS**


Parts Required:


RFX HANDRAIL TOOLS REQUIRED


1/8" HIGH SPEED DRILL	#2 PHILLIPS DRIVER	T25 TORX DRIVER	PENCIL
			
CORDLESS DRILL	LEVEL	C-CLAMP	TAPE MEASURE


RFX HANDRAIL PARTS REQUIRED



 HB-ADAMNT-XX



 RFXADA-XX



 RFXADACAP-XX



 RFXADASINT



 PAN-10-3/4-SS-XX


 RFXADAHRMM90-XX


 RFXADAHRMF90-XX


 RFXADAHR30-XX


 RFXADAHR33-XX


 RFXADAHR36-XX

NOTE: HOLES ON COMPONENTS ARE FOR POST-PROCESSING AND NOT FOR SCREW FASTENING



LEARN MORE ABOUT THE
RAILFX OASIS™ RAILING SYSTEM

(206) 453-1123

sales@railfx.net

railfx.net

RFX-022025-673250


LEAN ON US®

RAILFX OASIS™ SECONDARY HANDRAIL INSTALLATION INSTRUCTIONS




Step 1

Remove post cap and center the end cap on post - 32 ½" – 36 ½" from the top surface of the stair tread. Mark the center location of the end cap.




Step 2

Drill 1/8" pilot hole at the end cap mark from step 1. Secure end cap to post with a #10 x ¾" self-drilling screw.



Step 3

Assemble male-female elbow onto the end cap. Angle the elbow to align with the top rail angle.




Step 4

Attach handrail to elbow. Ensure length of handrail is enough to connect at top of stair landing.


Note: Do not fasten either fitting or handrail in this step!

RAILFX OASIS™ SECONDARY HANDRAIL INSTALLATION INSTRUCTIONS




Step 5

Rotate handrail to align with stair top rail. Place mount under handrail and rotate so handrail rests evenly on mount saddle.



Step 6


Mark location of mount. Drill 1/8" dia. pilot hole into post. Secure mount to post using the noted hardware.
Note: Do not fasten handrail to mount in this step!



Step 7

Assemble fittings onto stair handrail and rest handrail onto mount saddle.

Note: Ensure that end cap is positioned in center of post. If not, cut stair handrail as needed.




Step 7B - Straight

Note: Add RFXADASINT, if needed.


Use RFXADASINT when length of RFXADA-XX is short of what is needed to connect elbow to post landing.

RAILFX OASIS™ SECONDARY HANDRAIL INSTALLATION INSTRUCTIONS




Step 8 - 90°

Once handrail is resting on mount, mark location of end cap and drill 1/8" dia. pilot hole into post.



Step 9

Remove end cap from assembly and screw into post using #10 self-drilling screw.



Step 10

Drill 1/8" dia. pilot holes through all connection points.

Note: Holes should be drilled at bottom of connections.

Secure connections using #10 x 3/4" self-drilling screws.

